



Л (1:5)




обечайка поз. 53 и фланец поз. 55 не показаны
Shell pos. 53 and Flange pos. 55 not shown





П1-П1 (1:10) (4)




P1 (1:2)

Деталь поз. 54 (1:5)
DetailДеталь поз. 55 (1:5)
Detail



И (1:5)

Деталь поз. 106 (1:2)
Detail




К-К (1:5) (1)



Л-Л (1:5) (1)

Деталь поз. 107 (1:2)
Detail

Л1 (1:5) (1)

Деталь поз. 92 (1:5)
DetailСекция 16 поз.19 (1:10)
Section
907Секция 17 поз.20 (1:10)
Section
1327